2018-2022 Toyota C-HR - Check Engine Light / OBD2

2018-2022 Toyota C-HR | Easy | 15-30 minutes | $25 DIY

TOOLS

OBD-II scanner compatible with the vehicle
Flashlight Notebook or phone for codes and freeze-frame data Safety glasses

PARTS

OBD2 scanner $25.00

STEPS

1. **Confirm warning severity - Check whether the light is steady or flashing. Flashing means** a severe misfire that can overheat the catalytic converter - pull over and shut the 2.0L engine off. Companion VSC and traction control warnings are usually side effects that...
2. **Connect the OBD-II scanner - With the ignition off, find the 16-pin connector under the** dash, left of the steering column. Plug it in, switch the ignition to ON with the engine off, and confirm it links to the engine control module - a loose connection mimics a dead...
3. **Read and record codes - Scan and log every confirmed, pending, and permanent code plus** freeze-frame data before changing anything. Typical C-HR patterns: P0456 EVAP leak, P2195/P2196 air-fuel sensor lean/rich, P0138 downstream oxygen sensor high voltage, P0420 ca...
4. **Check the likely cause - For P2195 or P0171, upstream air-fuel voltage should hover near** 3.3 volts; a sensor stuck lean while fuel trims climb means a failing sensor or an exhaust leak ahead. For P0456, inspect the fuel cap seal, reinstall until it clicks, and che...
5. **Repair, clear, and verify - Once the true cause is fixed, clear the codes and run a** Toyota drive cycle: warm idle for a few minutes, steady cruising at 40 to 55 mph for several minutes, and gentle deceleration, with the tank between one-quarter and three-quarters ful...

ezcarfix.com

TORQUE