2023-2026 Toyota GR Corolla - Cabin Air Filter

2023-2026 Toyota GR Corolla | Easy | About 5-10 minutes | $28 DIY

TOOLS
No tools required - the damper lever, side hooks, and filter lid latches are all hand-operated

PARTS
Cabin air filter for 2023-2026 Toyota GR Corolla; verify arrows, size, and VIN/trim fitment $28.00

STEPS

1. **Confirm the location behind the glove box - The 2023-2026 GR Corolla keeps its cabin** filter directly behind the glove box, passenger side. Empty the glove box completely - the GR's box is shallow and anything left inside will jam it as you swing it down.
2. **Detach the damper lever on the right side - Pull the damper lever on the right edge of** the glove box to the right, off its hook - it slides off sideways. Don't pull downward or twist; the thin hook will crack. Hold the door with your other hand.
3. **Release the side hooks and lower the glove box fully - Release the hook on each side wall** - press or lift it clear of the dash, right then left - and pull the door down fully. The box hangs near-horizontal, revealing the HVAC housing and the rectangular filter lid.
4. **Pop the filter lid off its latches - Press the latches on the lid's edges and lift it** off. Keep your face back - the old filter's top sheds dust immediately. Note the printed arrows: on the Corolla family they point up, marking installed orientation. Copy it exactly.
5. **Pull the old filter and inspect the empty slot - Slide the old filter out level so debris** doesn't fall into the housing or blower. Check the empty slot for leaves, foam, or dust film and wipe out anything loose. The new filter must drop in without forcing.
6. **Slide in the new filter and snap the lid shut - Slide the new filter in with the arrows** pointing the same way the old filter's pointed (up). Push until fully seated - no corner out, no pleat folded under. Press the lid on until both latches snap; tug lightly to confirm.
7. **Rebuild the glove box and verify on the blower - Seat the glove box's side hooks, re-clip** the damper lever, and confirm it opens and latches normally. Run the blower at full speed through all modes - strong, even airflow, no whistling or rattling. Toyota's guidance: every 15,000-30,0...

TORQUE

ezcarfix.com