

2018-2024 Audi A5 | Easy | 30 minutes | \$25 DIY

TOOLS

Flathead Screwdriver Phillips Head
Screwdriver Trim Removal Tool 10mm
Socket Ratchet Wrench Flashlight
Gloves Safety Glasses

PARTS

Cabin Air Filter CUK 31 003 \$25.00

STEPS

- 1 Open and empty the glovebox - Open the glovebox and remove all contents. If there is a damper strut on one side, unclip it. Squeeze the sides (or release stops) so the glovebox drops fully open.**
- 2 Access the filter door - Behind the glovebox, locate the cabin filter cover/door. Release the clips or screws and remove the cover. Keep fasteners handy.**
- 3 Remove the old filter - Slide the old filter straight out. It is often dusty or moldy - bag it immediately. Wipe loose debris from the housing with a clean cloth or vacuum.**
- 4 Check airflow direction - Compare the new filter to the old one. The airflow arrow on most filters points down or toward the blower - match the arrow direction marked on the housing.**
- 5 Install the new filter - Slide the new filter fully into the housing until seated. Do not force an oversized filter; a poor seal lets unfiltered air bypass.**
- 6 Reassemble the glovebox - Reinstall the filter cover until clips click. Reconnect the damper if removed, push the glovebox back onto its stops, and reload contents. Run the fan and check for unusual noise.**