

2008-2013 BMW 328i | Easy | 15-25 minutes | \$20 DIY

TOOLS

Trim tool or flat screwdriver (optional)
Flashlight Gloves Vacuum or rag for debris

PARTS

Cabin air filter \$20.00

STEPS

- 1 Prep and open access - Park the 2008-2013 BMW 328i and set the parking brake. Empty the glovebox (or open the cabin-filter access panel under the dash / cowl if your BMW 328i uses that layout). Informational DIY - EZ Car Fix is not a shop.**
- 2 Expose the filter door - On the 2008-2013 BMW 328i, squeeze the glovebox side walls or release the dampener/stops so the box drops fully, then unclip the cabin air filter cover. Keep fasteners and clips together so none are lost under the dash.**
- 3 Remove the old filter and clean - Slide the old cabin air filter out of the BMW 328i housing. Note the airflow arrow direction first. Bag the dirty filter, then wipe or vacuum leaves and dust from the slot so debris does not enter the HVAC case.**
- 4 Install the new filter - Insert the new cabin air filter into the 2008-2013 BMW 328i housing with the airflow arrow matching the old filter (usually pointing down or toward the blower). Seat it fully - do not bend the frame or leave gaps at the edges.**
- 5 Reassemble and verify airflow - Refit the filter cover until it clicks, then reconnect the BMW 328i glovebox dampener/stops and close the glovebox. Start the 2008-2013 BMW 328i, set the fan to fresh air (not max recirculate), and confirm strong airflow with no rattle fro...**