

2016-2024 BMW X1 | Easy | 15 minutes | \$50 DIY

TOOLS

No specific tools required

PARTS

Front Wiper Blades 61612407291 \$49.99

STEPS

- 1 Service position (if needed) - Turn the ignition off. On many vehicles, briefly switch ignition on/off and pull the wiper stalk to park the arms in a raised service position. Otherwise carefully lift each arm by hand.**
- 2 Lift the wiper arm - Lift the wiper arm off the glass until it stays up. Support it - never let a bare arm snap back onto the windshield or you can crack the glass.**
- 3 Release the old blade - Locate the lock tab where the blade meets the arm (hook, pin, or bayonet). Press the tab and slide the blade off the arm. Note how the connector was oriented.**
- 4 Match the new blade - Confirm the new blade length and connector type match the old one. Attach any adapter included with the new blade before installing.**
- 5 Install until it clicks - Slide or clip the new blade onto the arm until you hear/feel a solid click. Tug gently to confirm it is locked.**
- 6 Lower and repeat - Gently lower the arm onto the glass. Repeat for the other side (and rear wiper if equipped). Mist the glass and run the wipers to verify streak-free contact.**