

2013-2019 Cadillac ATS | Moderate | 30-60 minutes | \$140 DIY

TOOLS

Socket set Wrench set Terminal brush
Battery protectant Gloves Safety glasses

PARTS

Correct group-size battery \$140.00
Terminal cleaner \$8.00
Terminal protectant \$7.00

STEPS

- 1 Prep and disconnect - Park the 2015-2020 Cadillac ATS, set parking brake. Optional memory saver. Disconnect negative then positive. Informational DIY - EZ Car Fix is not a shop.**
- 2 Remove old battery - Remove hold-down, lift battery from the 2015-2020 Cadillac ATS tray, clean tray/terminals.**
- 3 Install new battery - Seat correct group-size battery, secure hold-down, connect positive then negative, protect terminals on the 2015-2020 Cadillac ATS.**
- 4 Verify - Start the 2015-2020 Cadillac ATS, confirm charging warnings clear, reset clock; recycle old battery.**

TORQUE

Battery hold-down 11 Nm 8 ft-lbs