

2010-2016 Cadillac SRX | Advanced | 2-3 hours | \$150 DIY

TOOLS

1/4 Inch Ratchet Torque Wrench Gloves
T30 Bit 8mm Socket Hose Clamp Pliers
10mm Socket 5/8 Inch Spark Plug Socket
3/8 Inch Drive Ratchet Safety Glasses
T25 Torx Driver

PARTS

ACDelco 41-109 Spark Plugs 41-109 \$77.95
ACDelco Ignition Coils D515C \$225.95

STEPS

- 1 Cool the engine - Work only on a cold engine. Hot aluminum heads can pull threads when plugs are removed.** Disconnect the negative battery terminal if required by your procedure.
- 2 Access the ignition coils - Remove any engine cover or intake tube blocking the coils.** Label coil connectors or photograph their positions before unplugging.
- 3 Remove one coil at a time - Unplug the coil connector, remove the coil hold-down bolt, and pull the coil straight up.** Work one cylinder at a time to avoid mixing parts.
- 4 Remove the old spark plug - Blow loose dirt from the well. Use a spark-plug socket with a rubber insert and extension to remove the plug.** Inspect the tip for oil, coolant, or abnormal wear.
- 5 Gap and hand-thread the new plug - Confirm the new plug part number and set the gap to the manufacturer specification if required (many iridium plugs are pre-gapped). Start the plug by hand to avoid cross-threading.**
- 6 Torque to specification - Torque the plug to the spec in the service information** (typically a modest ft-lb or degree turn after seating). Do not overtighten - stripped head threads are expensive.
- 7 Reinstall the coil - Press the coil fully onto the plug, reinstall the hold-down bolt to snug/spec, and reconnect the electrical connector until it clicks.**
- 8 Reassemble and test - Refit covers/intake components, reconnect the battery if removed, and start the engine.** Listen for misfires and confirm a smooth idle. Clear any residual codes if a light remains.

TORQUE

Spark plugs 18 Nm 13 ft-lbs