2020-2024 Cadillac XT6 - Wiper Blade Replacement

2020-2024 Cadillac XT6 | Easy | 10-15 minutes | $81 DIY

TOOLS

Tape measure or ruler (to settle the 11-vs-12-inch rear-blade question) Soft cloth or folded towel (to cushion the glass under a bare arm) Glass cleaner and paper towels (to clean the windshield, especially the Rainsense sensor area)

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 20" Bosch 20B $32.99
Rear wiper blade, 12" $14.99

STEPS

1. **Buy 24 and 20 front blades, and measure the rear blade - The rear wiper is a 12-inch** blade on a small hook arm - but measure it, because one catalog lists 11 inches while the original-equipment listings and most charts say 12.
2. **Stop the blades mid-wipe with Rainsense off - First, make sure the Rainsense auto-wipe is** switched off - the sensor sits near the top center of the windshield and you do not want it triggering a sweep mid-job.
3. **Open the latch and release the driver’s blade - Lift the driver’s arm away from the glass** until it holds upright, and lay your towel on the windshield beneath it. Open the small latch on the blade’s center connector - the owner’s procedure describes pulling the blade assembly down tow...
4. **Latch the new 24-inch driver’s blade on - Push the new 24-inch blade’s connector onto the** arm’s J-hook until the release lever clicks into place, then close the latch. Tug it firmly to confirm the lock - a half-latched blade can slide off the hook at highway speed.
5. **Swap the 20-inch passenger-side blade - Repeat the latch-and-lever procedure on the** passenger side with the 20-inch blade. Confirm the lock with a firm tug and lower the arm gently back to the glass.
6. **Replace the rear wiper using the accessory-mode procedure - Now the liftgate. The owner’s** procedure: put the vehicle in accessory mode and switch the rear wiper on - it will stop pointing downward - then switch the vehicle fully off and pull the wiper arm away from the rear glass. Release the s...
7. **Test everything and note the Rainsense and HUD glass quirks - With all three arms resting** on glass, start the vehicle and run the washers front and rear through several cycles. You want silent, streak-free sweeps edge to edge, with the rear blade parking flat and not overrunning the glass. Two XT6-sp...

TORQUE

ezcarfix.com