2017-2023 Chevrolet Bolt EV - Wiper Blade

2017-2023 Chevrolet Bolt EV | Easy | 15-20 minutes for all three blades | $81 DIY

TOOLS

New rear wiper blade - 12 inches per owner's manual (measure the old blade; some charts list 11 inches) Plastic trim tool (for the rear blade cover) Tape measure or ruler Microfiber cloth and glass cleaner Folded towel (to cushion the windshield under a bare arm)

PARTS

Driver wiper blade, 26" Bosch 26A $32.99
Passenger wiper blade, 26" Bosch 26B $32.99
Rear wiper blade, 12" $14.99

STEPS

1. **Confirm the blade sizes - 26, 26, and about 12 inches - Both front blades are 26 inches** (68 cm per the owner's manual). Buy push-button (top-lock, 22 mm) blades - hook-style blades won't fit. Rear: manual says 30 cm (sold as 12), some charts say 11; measure the old blade.
2. **Park the car and pull the front arms away from the glass - Switch off - no service** position needed. Lift each arm away from the glass, gripping near the hinge. Slide a folded towel under each arm: the manual warns a bare arm can damage the glass, and that damage isn't covered by the vehicle warr...
3. **Remove the old driver-side blade - press the center button - 2018+: press the middle** button on the arm connector and pull the blade off. 2017: flip open the cover, push the release lever, and push the arm out. Support the arm with your other hand; note the connector's orientation.
4. **Install the new 26-inch driver-side blade - Push the new 26-inch blade onto the connector** until the center button clicks into lock, then pull firmly - an unseated connector releases when the wipers reverse. On 2017 cars, snap the cover down afterward. Lower the arm gently, holding...
5. **Replace the 26-inch passenger-side blade - Repeat the same procedure on the passenger** side: same 26-inch length, same push-button connector, same press-and-pull removal. Seat the new blade until it clicks and rest the arm on the glass.
6. **Replace the rear wiper blade - remove its cover first - Pry off the rear cover with a** trim tool. Press the release lever, slide out the old blade, and fit the new 12-inch blade (some charts say 11 - match your measurement) until it clicks. Refit the cover in the slot and snap it down.
7. **Test the wipers and washers - Switch on and run the washers at low and high speed plus a** rear cycle. New blades should clear without streaks, skipping, or chatter. If a front blade chatters, recheck its push-button connector is fully locked. Wipe edges with a damp clot...

TORQUE

ezcarfix.com