2019-2024 Chevrolet Silverado 1500 | Easy | 10-20 minutes | $20 DIY

TOOLS
Rag or shop vacuum Gloves

PARTS
Engine air filter $20.00

STEPS

1. **Prep and confirm the filter part number - Get the right filter: OEM spec is an ACDelco** A3244C (or equivalent) for the 5.3L V8. Confirm the part number against your old filter first.
2. **Open the air filter housing - Release the spring clips around the lid with your fingers,** working around the perimeter, then lift the lid straight up - the attached ducting means you tilt rather than fully remove it.
3. **Remove the old filter and clean - Lift the old filter out, noting which way it sat and** which way its airflow arrow pointed. Vacuum the box bottom, keeping debris away from the intake opening. Don’t disturb the MAF sensor in the intake tract just past the box.
4. **Install the new filter - Drop the new filter in with its arrow pointing the right way and** its rubber edge fully seated in the groove. Press around the perimeter: flat, no gaps or folded pleats. Rocking or sitting proud means it’s upside down or the wrong part.
5. **Reseal and verify - Set the lid onto its alignment tabs and snap each clip shut with** positive tension. Tug the lid to confirm every clip is engaged. Reset the air filter life monitor through the driver information center.

ezcarfix.com