

2015-2020 Chevrolet Suburban | Advanced | 1-3 hours | \$180 DIY

TOOLS

Floor jack, rated jack stands, and wheel chocks  
Lug wrench and calibrated torque wrench  
Brake piston compressor or suitable spreader  
Socket set, wire brush, brake cleaner, gloves, and eye protection

PARTS

Front or rear brake pad set for 2015-2024 Chevrolet Suburban; verify axle, brake package, and VIN fitment \$180.00  
Replacement pad hardware or wear sensor only if the kit requires it \$25.00

STEPS

- 1
- Confirm axle, parts, and brake condition - Verify the front or rear axle, pad shape,** brake package, rotor thickness, and wear-sensor arrangement for the 2015-2024 Chevrolet Suburban. Read the owner/service information for the exact torque values.
- 2
- Lift and secure the vehicle - Park the 2015-2024 Chevrolet Suburban level, set the** parking brake only as appropriate for the axle being serviced, chock the wheels, loosen lug nuts, and support the vehicle on rated jack stands.
- 3
- Remove the caliper and old pads - Remove the wheel and caliper hardware on the 2015-2024** Chevrolet Suburban. Support the caliper with a hook, remove the old pads and hardware, and inspect the rotor, pins, boots, hose, and piston for damage or leaks.
- 4
- Install pads and hardware - Clean the bracket contact points, install the correct** hardware and pads on the 2015-2024 Chevrolet Suburban, and retract the piston only with the correct tool and procedure. Keep friction surfaces free of grease and brake cleaner residue.
- 5
- Torque, pump, and bed in - Reinstall the caliper and wheel on the 2015-2024 Chevrolet** Suburban using exact vehicle-specific torque, pump the pedal until firm before moving, verify fluid level, and follow the pad maker's moderate bedding procedure in a safe area.

TORQUE