2015-2020 Chevrolet Suburban - Cabin Air Filter

2015-2020 Chevrolet Suburban | Easy | 15-25 minutes | $28 DIY

TOOLS
Phillips screwdriver or small socket set (for trim-panel fasteners on some trims) shop vacuum or damp cloth flashlight

PARTS
Cabin air filter for 2015-2020 Chevrolet Suburban; verify arrows, size, and VIN/trim fitment $28.00

STEPS

1. **Confirm fitment and find the filter - K2XX Suburban (2015-2020, LS/LT/LTZ/Premier): cabin** filter sits behind the glove box, same as Tahoe and Silverado siblings. Check behind your glove box before forcing anything.
2. **Prep the car and clear the glove box - Ignition off, key or fob with you so the blower** stays silent. Empty the glove box completely - it'll be lowered or removed. If your trim has the side trim panel, have a Phillips or small socket ready for its fasteners, plus a flashlight.
3. **Lower the glove box (or remove the trim panel) - Unhook the damper arm from the glove** box's right side. Squeeze both side walls inward past the stops; let it rotate down on its hinges. If a side trim panel blocks access, pop it off first, then remove the insulator panel fasteners and pan...
4. **Release the cover and remove the old filter - Release the rectangular cover's clips or** tabs behind the glove box and pull it off. Slide the old filter straight out. Study the printed airflow arrow before discarding - the replacement must point the same way. Expect a gray, packed fil...
5. **Clean the housing and prep the new filter - Vacuum or wipe the housing and cover; keep** debris out of the open slot - it leads straight to the blower. Hold the new filter against the old to confirm arrow direction; check the new frame is straight so it seals evenly.
6. **Install the filter and reassemble - Slide the new filter in flat so edges seal; press the** cover until clips catch. Reinstall insulator panel and fasteners, then snap the trim cover on. Swing the glove box up past the stops, rehook the damper arm, and confirm smooth open and...
7. **Test the HVAC and set a replacement habit - Run the fan low to high on fresh air: strong** steady airflow at the passenger vents, no whistles or rattles (unseated cover or trim). Stale smell should clear immediately. Most replace yearly, sooner after dusty summers.

ezcarfix.com