# 2015-2020 Chevrolet Suburban - Tire Pressure Light



**2015-2020 Chevrolet Suburban | Moderate | 45-75 minutes | $0 DIY**

**TOOLS**

Tire pressure gauge  Air compressor or pump  Floor jack  Jack stands  Lug wrench  Torque wrench  Wheel chocks  Breaker Bar

**PARTS**

Valve stem caps (optional) $6.00

## STEPS

1. **Read door-jamb PSI and inspect tires - On the 2015-2020 Chevrolet Suburban, open the** driver door and read the tire-and-loading placard for cold front/rear PSI - the placard lists values for normal and maximum loads, so use the row matching how you drive, and never substitute...
2. **Set cold pressures / clear TPMS if low - With the tires cold, set each tire to the exact** placard PSI with your own gauge. Some trims can enter learn mode from the driver information center instead of the fob - check your manual.
3. **Jack and stand - On level ground, set the parking brake and chock the wheels. Jack at the** factory lift points and support this heavy SUV on stands rated for its weight; never rely on the jack alone.
4. **Rotate per the correct pattern - Confirm against the owner's-manual diagram. Directional** tires stay on their original side and only swap front-to-back. Hand-start every lug nut to avoid cross-threading the 14mm studs, then snug in a star pattern while the wheel is in the...
5. **Lower and torque star pattern - Lower the Suburban until the tires bear weight, then** torque the lug nuts in a star pattern to 140 ft-lb (190 N-m) - the GM truck spec, confirmed in the owner's manual. Recheck torque after 50-100 miles. Then do the TPMS relearn from step...

**TORQUE**

Wheel lug nuts (star pattern - confirm in owner manual) 190 Nm 140 ft-lbs

ezcarfix.com