

2021-2024 Chevrolet Tahoe | Easy | 15 minutes | \$60 DIY

TOOLS

Flathead Screwdriver 10mm Socket
Ratchet Wrench Pry Bar Gloves

PARTS

Windshield Wiper Blades \$30.00
Windshield Wiper Blades \$30.00

STEPS

- 1 Service position (if needed) - Turn the ignition off. On many vehicles, briefly switch ignition on/off and pull the wiper stalk to park the arms in a raised service position. Otherwise carefully lift each arm by hand.**
- 2 Lift the wiper arm - Lift the wiper arm off the glass until it stays up. Support it -** never let a bare arm snap back onto the windshield or you can crack the glass.
- 3 Release the old blade - Locate the lock tab where the blade meets the arm (hook, pin, or bayonet). Press the tab and slide the blade off the arm. Note how the connector was oriented.**
- 4 Match the new blade - Confirm the new blade length and connector type match the old one.** Attach any adapter included with the new blade before installing.
- 5 Install until it clicks - Slide or clip the new blade onto the arm until you hear/feel a solid click. Tug gently to confirm it is locked.**
- 6 Lower and repeat - Gently lower the arm onto the glass. Repeat for the other side (and rear wiper if equipped). Mist the glass and run the wipers to verify streak-free contact.**