2011-2017 Chrysler 200 - Wiper Blade Replacement

2011-2017 Chrysler 200 | Easy | 10-15 minutes | $66 DIY

TOOLS

No tools required Tape measure - to confirm 24"/22" (2011-2014) or 26"/19" (2015-2017) Clean cloth - to protect the glass under raised arms Fine pin - to clear clogged washer nozzles (optional)

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 22" Bosch 22B $32.99

STEPS

1. **Identify your generation: 2011-2014 takes 24/22, 2015-2017 takes 26/19 - The 2015** redesign changed the wiper sizes. First-gen (2011-2014, sedan and convertible): 24-inch driver, 22-inch passenger. Second-gen (2015-2017, sedan): 26-inch driver, 19-inch passenger. Check the door jamb sticker; the pairs aren't...
2. **Park, power off, and set up - Park level, ignition off, wiper stalk OFF. No service** position - lift arms off the glass. On 2015+ the hood edge sits close, so lift back without levering on the hood. Towel under the arm; one side at a time.
3. **Remove the driver-side blade from the J-hook - Lift the arm and find the connector's** release tab or button - you press a tab or lift a latch. Slide it down off the hook; keep it parallel - twisting bends hooks. Verify: 24 for 2011-2014, 26 for 2015-2017.
4. **Install the new driver-side blade - Feed the J-hook through the connector and slide it up** until the tab clicks. Tug - a loose blade can work off over weeks. Lower gently. On rain-sensor cars (2015+), keep the mirror sensor area clean; blades install the same.
5. **Repeat on the passenger blade - Repeat on passenger side with length: 22 for 2011-2014,** 19 for 2015-2017. A 22-inch blade on a 2015+ car overruns the glass edge; a 19-inch blade on a car leaves a gap. When in doubt, compare against the old first.
6. **Inspect the arms and cowl while you're there - Check the hinge for stiffness or rust - a** binding hinge stops even pressure, and new blades can't fix streaking. It should move freely. Clear the cowl grille, run the washers, clear clogs with a pin, top up the fluid.
7. **Test both speeds and confirm the park position - Turn the ignition on and run the wipers** at all speeds. Watch for streaks, skipped sections, chatter, and clicking meaning a connector isn't latched. Confirm both arms park flat. Tape your sizes (24/22 or 26/19) inside the glove box.

ezcarfix.com