

2001-2010 Chrysler PT Cruiser | Easy | 15-30 minutes | \$25 DIY

TOOLS

OBD-II scanner compatible with the vehicle
Flashlight Notebook or phone for codes
and freeze-frame data Safety glasses

PARTS

OBD2 scanner \$25.00

STEPS

- 1 Confirm warning severity - Determine whether the check-engine light on the 2001-2010 Chrysler PT Cruiser is steady or flashing.** A flashing lamp, severe shaking, overheating, or loss of power calls for stopping safely rather than continuing a DIY scan.
- 2 Connect the OBD-II scanner - Turn the ignition off, locate the diagnostic-link connector** under the the 2001-2010 Chrysler PT Cruiser dashboard, and plug in a compatible OBD-II scanner without forcing it.
- 3 Read and record codes - Run a full scan on the 2001-2010 Chrysler PT Cruiser. Record** confirmed, pending, and permanent codes plus freeze-frame data such as RPM, coolant temperature, and speed before clearing anything.
- 4 Check the likely cause - Use the code and freeze-frame clues to inspect the 2001-2010 Chrysler PT Cruiser wiring, connectors, fuses, intake hoses, fuel cap, fluid leaks, and vacuum or exhaust leaks.** A code identifies a monitored fault, not automatically a failed C...
- 5 Repair, clear, and verify - After correcting the root cause on the 2001-2010 Chrysler PT Cruiser, clear codes only if appropriate, complete a normal drive cycle, and rescan for** returning codes or readiness-monitor issues.

TORQUE