

2014-2024 Infiniti Q50 | Easy | 15 minutes | \$25 DIY

TOOLS None	PARTS Engine Coolant (50/50 mix) 999MP-AF050P \$20.00 Funnel FNL-001 \$5.00
----------------------	--

STEPS

- 1 Cool the engine completely - Never open a hot radiator or coolant reservoir cap -** the system is pressurized and can spray scalding coolant. Wait until the engine is fully cool to the touch.
- 2 Locate the reservoir and check level - Find the translucent coolant overflow/expansion** tank. Note the MIN/MAX (or COLD/HOT) marks. Confirm whether this vehicle is topped off at the reservoir only or also at a radiator cap.
- 3 Identify the correct coolant - Use only the coolant type specified for this make (color** alone is not a reliable guide). Have premix or concentrate plus distilled water ready. Never mix incompatible formulas.
- 4 Add coolant to the cold fill mark - Remove the reservoir cap (and radiator cap only if** the procedure requires it and the engine is cold). Add coolant slowly to the cold full mark. Wipe spills off painted surfaces immediately.
- 5 Bleed and recheck after a drive - Start the engine with the heater on high. Watch the** level as air works out; top off as needed. After the engine cools from a short drive, recheck the level and look for leaks or a rising temperature gauge.