2014-2024 Infiniti Q50 - Wiper Blade Replacement

2014-2024 Infiniti Q50 | Easy | 10-15 minutes | $66 DIY

TOOLS

26-inch driver blade and 17-inch (measure first - some charts say 16-inch) passenger blade with hook adapters Tape measure Clean microfiber cloth Glass cleaner Folded towel (to protect the windshield while blades are off)

PARTS

Driver wiper blade, 26" Bosch 26A $32.99
Passenger wiper blade, 17" Bosch 17B $32.99

STEPS

1. **Confirm the sizes and buy the blades - The 2014-2024 Infiniti Q50 takes a 26-inch blade** on the driver side. The passenger side is 17 inches on most fitment charts, though a few list 16 inches - measure your old passenger blade with a tape before buying to be sure.
2. **Park the wipers and lift the driver-side arm - Turn the Q50 off and confirm the wipers** are parked at the base of the windshield. Do one side at a time so the 26-inch driver blade and the shorter passenger blade never get confused.
3. **Release the old driver-side blade from the offset hook - The Q50 uses an offset** hook-style arm. Lift the driver-side arm, then locate the release tab where the blade's adapter sits in the hook. Press the tab and slide the long 26-inch blade down out of the hook. Hold the bare arm with your other...
4. **Prep the new 26-inch blade - Pull the protective sleeve off the new blade without** touching the rubber edge. Make sure the blade's adapter is configured for a hook arm - most aftermarket blades include a small adapter you snap into the hook position.
5. **Hook the new blade on and check the lock - Slide the new 26-inch blade into the arm's** hook and pivot it up until the adapter clicks. Ease the arm back down onto the windshield, controlling it all the way.
6. **Install the passenger blade - Repeat the tab-release and hook install for the passenger** blade - 17 inches on most Q50s, 16 on some. Double-check: the 26-inch blade belongs on the driver side; a short blade on the wrong side leaves a large unwiped area.
7. **Test with washer fluid - Start the car, spray washer fluid, and run the wipers through** intermittent, low, and high speeds. The big 26-inch driver blade should clear its full arc without streaks or skips at the tip. If the passenger blade misses the outer edge of t...

ezcarfix.com