

2011-2021 Jeep Grand Cherokee | Easy | 15-25 minutes | \$20 DIY

TOOLS

Trim tool or flat screwdriver (optional)
Flashlight Gloves Vacuum or rag for debris

PARTS

Cabin air filter \$20.00

STEPS

- 1 Prep and open access - Park the 2011-2016 Jeep Grand Cherokee and set the parking brake.**
Empty the glovebox (or open the cabin-filter access panel under the dash / cowl if your Jeep Grand Cherokee uses that layout). Informational DIY - EZ Car Fix is not a shop.
- 2 Expose the filter door - On the 2011-2016 Jeep Grand Cherokee, squeeze the glovebox side walls or release the dampener/stops so the box drops fully, then unclip the cabin air filter cover.** Keep fasteners and clips together so none are lost under the dash.
- 3 Remove the old filter and clean - Slide the old cabin air filter out of the Jeep Grand Cherokee housing.** Note the airflow arrow direction first. Bag the dirty filter, then wipe or vacuum leaves and dust from the slot so debris does not enter the HVAC case.
- 4 Install the new filter - Insert the new cabin air filter into the 2011-2016 Jeep Grand Cherokee housing with the airflow arrow matching the old filter (usually pointing down or toward the blower).** Seat it fully - do not bend the frame or leave gaps at the edges.
- 5 Reassemble and verify airflow - Refit the filter cover until it clicks, then reconnect the Jeep Grand Cherokee glovebox dampener/stops and close the glovebox.** Start the 2011-2016 Jeep Grand Cherokee, set the fan to fresh air (not max recirculate), and confirm strong airf...