2016-2023 Mercedes-Benz Metris - Wiper Blade

2016-2023 Mercedes-Benz Metris | Easy | 15-20 minutes | $66 DIY

TOOLS

Clean rag Sturdy step (the van's windshield is tall)

PARTS

Driver wiper blade, 28" Bosch 28A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99
Rear wiper blade, 15" (dual-rear vans - need two) $14.99
Rear wiper blade, 16"

STEPS

1. **Confirm the sizes and buy the blades - The Metris (W447) takes a 28-inch driver blade,** 18-inch passenger blade, and 16-inch rear blade - confirm yours isn't the larger Sprinter, which takes different blades. Vans with wipers on both rear doors take two 15-inch rear blades ins...
2. **Move the wipers to the service position - The Metris parks its wipers low near the hood -** set the service position before lifting: ignition on, then off, and within ten seconds tap the stalk down once. Never force an arm against the hood edge.
3. **Release the old blade from the slide-clip arm - The front arms use a Mercedes slide-clip** (top-lock) connector. Rotate the blade fully away from the arm, slide the plastic cap forward to unlock, and pull the blade off. Hold the bare arm - these tall arms carry strong spring tension.
4. **Prep the new 28-inch blade - Unbox the new 28-inch blade and confirm the slide-clip** connector is pre-fitted - Metris-specific blades come with it installed. Strip the protector sleeve off the rubber, then hold it against the old blade to confirm the 28-inch length,...
5. **Install the driver blade and lock the cap - Slide the new 28-inch blade on and push the** cap back to locked until it clicks - that click is the lock. Tug to confirm it can't slide off. Lower the arm by hand, standing where you can control it on the tall windshield.
6. **Swap the passenger blade and the rear blade - Repeat the slide-cap swap for the 18-inch** passenger blade - confirm the 28 is on the driver side. At the rear, lift the arm, release the old 16-inch blade, and click the new one on. Dual-rear-wiper vans: do both 15-inch blades the same w...
7. **Exit service position and test with washer fluid - Run the wipers once to exit service** position, then spray washer fluid - never test dry. Both fronts should sweep wide, quiet, and streak-free on the big upright windshield. Run the rear washer and wiper to confirm the rear blade clears i...

TORQUE

ezcarfix.com