

1996-2024 Mercedes-Benz Vito | Easy | 10-20 minutes | \$35 DIY

TOOLS

Soft towel to protect the glass Small flat screwdriver only if the adapter requires it Gloves and a clean cloth

PARTS

Front/rear wiper blade set for 1996-2024 Mercedes-Benz Vito; verify lengths and connector type \$35.00

STEPS

- 1 Confirm blades and adapters - Measure or verify the front/rear blade lengths and connector style for the 1996-2024 Mercedes-Benz Vito.** Compare every replacement adapter before removing the old blade.
- 2 Protect the glass - Lift one arm on the 1996-2024 Mercedes-Benz Vito at a time and place** a folded towel on the windshield. Never allow a bare spring-loaded arm to snap onto the glass.
- 3 Remove the old blade - Release the locking tab or pin on the 1996-2024 Mercedes-Benz Vito** and slide the old blade off without bending the arm. Retain any vehicle-specific adapter that the new blade requires.
- 4 Install and lock the new blade - Slide the correct blade onto the arm of the 1996-2024** Mercedes-Benz Vito until the latch clicks, then tug lightly to confirm it is locked and rests in the original position.
- 5 Test with washer fluid - Lower the arm gently, fill or check washer fluid, and test the** 1996-2024 Mercedes-Benz Vito on wet glass. Replace a damaged arm or investigate streaking caused by glass contamination or linkage problems.

TORQUE