

2003-2007 Nissan Murano | Easy | 10-20 minutes | \$35 DIY

TOOLS

Soft towel to protect the glass
Small flat screwdriver only if the adapter requires it
Gloves and a clean cloth

PARTS

Driver wiper blade, 26" Bosch 26A
Passenger wiper blade, 18" Bosch 18B
Rear wiper blade, 14"

STEPS

- 1 Get the right blades: 26" driver, 18" passenger** - The 2003-2007 Nissan Murano takes a 26-inch blade on the driver side and a 18-inch blade on the passenger side. It also has a 14-inch rear wiper blade. 2003-2005 models take a 19-inch passenger blade; 2006 and later take 18-inch.
- 2 Protect the glass** - Lift one arm on the 2003-2007 Nissan Murano at a time and place a folded towel on the windshield. Never allow a bare spring-loaded arm to snap onto the glass.
- 3 Remove the old blade** - Release the locking tab or pin on the 2003-2007 Nissan Murano and slide the old blade off without bending the arm. Retain any vehicle-specific adapter that the new blade requires.
- 4 Install and lock the new blade** - Slide the correct blade onto the arm of the 2003-2007 Nissan Murano until the latch clicks, then tug lightly to confirm it is locked and rests in the original position.
- 5 Test with washer fluid** - Lower the arm gently, fill or check washer fluid, and test the 2003-2007 Nissan Murano on wet glass. Replace a damaged arm or investigate streaking caused by glass contamination or linkage problems.