

2003-2008 Nissan Murano | Easy | 10-20 minutes | \$35 DIY

TOOLS

Soft towel to protect the glass Small flat screwdriver only if the adapter requires it Gloves and a clean cloth

PARTS

Front/rear wiper blade set for 2003-2012 Nissan Murano; verify lengths and connector type \$35.00

STEPS

- 1 Confirm blades and adapters - Measure or verify the front/rear blade lengths and connector style for the 2003-2012 Nissan Murano.** Compare every replacement adapter before removing the old blade.
- 2 Protect the glass - Lift one arm on the 2003-2012 Nissan Murano at a time and place a folded towel on the windshield.** Never allow a bare spring-loaded arm to snap onto the glass.
- 3 Remove the old blade - Release the locking tab or pin on the 2003-2012 Nissan Murano and slide the old blade off without bending the arm.** Retain any vehicle-specific adapter that the new blade requires.
- 4 Install and lock the new blade - Slide the correct blade onto the arm of the 2003-2012 Nissan Murano until the latch clicks, then tug lightly to confirm it is locked and rests in the original position.**
- 5 Test with washer fluid - Lower the arm gently, fill or check washer fluid, and test the 2003-2012 Nissan Murano on wet glass.** Replace a damaged arm or investigate streaking caused by glass contamination or linkage problems.