

2013-2020 Nissan Pathfinder | Easy | 15 minutes | \$59 DIY

TOOLS

None required

PARTS

Front Windshield Wiper Blades 26" Driver Side, 19" Passenger Side \$49.00
Rear Windshield Wiper Blade 10" Rear \$10.00

STEPS

- 1 Service position (if needed) - Turn the ignition off. On many vehicles, briefly switch ignition on/off and pull the wiper stalk to park the arms in a raised service position. Otherwise carefully lift each arm by hand.**
- 2 Lift the wiper arm - Lift the wiper arm off the glass until it stays up. Support it -** never let a bare arm snap back onto the windshield or you can crack the glass.
- 3 Release the old blade - Locate the lock tab where the blade meets the arm (hook, pin, or bayonet). Press the tab and slide/unhook the old blade off the arm.**
- 4 Match the new blade - Confirm the new blade length and connector type match the old one.** Attach any adapter included with the blade kit for your arm style.
- 5 Install until it clicks - Slide or clip the new blade onto the arm until you hear/feel a solid click. Tug gently to verify it is locked before lowering.**
- 6 Lower and repeat - Gently lower the arm onto the glass. Repeat for the other side (and rear wiper if equipped). Mist the windshield and test wipe on low before driving.**