

2012-2019 Porsche 911 | Moderate | 2-3 hours | \$150 DIY

TOOLS

36mm Socket
Drain Plug Removal Tool
Torque Wrench
Oil Catch Pan
Funnel
Rubber Gloves
Flathead Screwdriver
Paper Towels or Rags
Jack Stands
Plastic Sheeting

PARTS

Liqui Moly Leichtlauf High Tech 5W-40
Engine Oil (5L) LM2332 \$59.95
Pentosin Pento High Performance II 5W-40
Engine Oil (5L) G052167M2 \$59.95
Porsche Oil Filter (9A110720391)
9A110720391 \$30.00
Porsche Drain Plug Seal (900-123-131-30)
900-123-131-30 \$4.00
Porsche Oil Filter Cap Gasket
(900-123-159-20) 900-123-159-20 \$4.00

STEPS

- 1 Prepare the Vehicle - Park on a level surface, engage the parking brake, and let the engine cool for at least 30 minutes.** Gather all tools, oil, and filter. Informational DIY. EZ Car Fix is not a shop.
- 2 Lift and Secure the Vehicle - Use a floor jack to lift the front of the vehicle at the designated jacking points.** Support with jack stands - never work under a vehicle supported only by a hydraulic jack.
- 3 Drain the Old Oil - Position the drain pan under the oil pan. Remove the drain plug with the appropriate socket.** Allow all oil to fully drain - this may take 5-10 minutes.
- 4 Replace the Oil Filter - Locate the oil filter. Use an oil filter wrench to remove the old filter.** Lubricate the new filter's rubber gasket with fresh oil, then install and hand-tighten.
- 5 Reinstall the Drain Plug - Install a new drain plug washer if applicable, then thread the drain plug back in by hand to avoid cross-threading.** Torque to specification using a torque wrench.
- 6 Add New Oil and Verify - Lower the vehicle. Remove the oil filler cap, insert a funnel, and pour in the specified amount and viscosity of new oil.** Start the engine, check for leaks, then check the dipstick level and top off as needed.

TORQUE

Oil Drain Plug 30 Nm 22 ft-lbs
Oil Filter Housing 25 Nm 18 ft-lbs