# 2011-2018 Porsche Cayenne - Cabin Air Filter



**2011-2018 Porsche Cayenne | Easy | 15-25 minutes | $20 DIY**

**TOOLS**

Trim tool or flat screwdriver (optional) Flashlight Gloves Vacuum or rag for debris T20 Torx Bit

**PARTS**

Cabin air filter $20.00

## STEPS

1. **Prep and open access - Park on level ground, brake set, ignition off. The filter sits in** the passenger footwell by the firewall - the glovebox stays shut. Slide the seat back and fold back the footwell carpet or trim panel.
2. **Expose the filter door - Release the filter cover tabs at the bottom of the HVAC case.** Pull the cover straight off and set it aside. No tools needed. The filter sits above the blower - keep the area clear while the cover is off.
3. **Remove the old filter and clean - Slide the old filter out, noting the arrow direction.** Bag it and vacuum the empty slot so debris doesn't fall onto the blower below.
4. **Install the new filter - Slide the new cabin air filter up into the 2011-2018 Porsche** Cayenne housing, oriented exactly like the old one (note the airflow arrows before discarding the old element). It must sit flat with no buckled pleats - withdraw and realign i...
5. **Reassemble and verify airflow - Refit the cover until its tabs click, then smooth the** footwell carpet back and slide the seat forward. Start the engine and run the HVAC on fresh air through several speeds - strong, clean airflow, no whistling or trim rattles.

ezcarfix.com