2015-2024 Porsche Macan - Battery Replacement

2015-2024 Porsche Macan | Moderate | 30-45 minutes | $140 DIY

TOOLS

10mm wrench or socket 13mm socket with extension T30 Torx bit trim removal tool (optional) nitrile gloves safety glasses memory saver (optional)

PARTS

Correct group-size battery $140.00
Terminal cleaner $8.00
Terminal protectant $7.00

STEPS

1. **Stage the car and clear the cargo area - Park the Macan on flat ground, switch the** ignition off, remove the key, and set the parking brake. The battery on the 95B Macan is not under the hood - it lives in the rear cargo area, so clear the trunk completely.
2. **Dig down through the spare tire - Open the rear hatch and lift the cargo floor cover by** its handle. Remove the rear cover to expose the spare, then unscrew the big plastic retaining lug and lift the spare tire out. On models with the factory subwoofer sitting over the batt...
3. **Expose the battery and photograph its labels - Lift the carpet lid below where the spare** sat to expose the battery. Note the negative ground strap on the passenger side: its nut is captive on the stud and should be loosened, not forced off.
4. **Disconnect the negative terminal first - Using a 10mm wrench, loosen the ground strap on** the negative post - marked with a minus on the passenger side - and lift it off. Loosen the captive nut only; it is not meant to come off the stud, and forcing it will damage the terminal...
5. **Vent hose off, bracket out, battery up - With the positive 10mm cable loosened and lifted** off its post, pull the vent line off the battery's vent port on the passenger-facing side and move it aside - you will reconnect it to the new battery. Remove the bolt holding the battery...
6. **Install the new battery and reconnect in order - Lower the new battery into the well with** the posts in the same orientation as the old one, refit the retaining bracket, and snug the 13mm bolt. Push the vent hose firmly back onto the vent port - a battery venting into the cabin is a gen...
7. **Reassemble - Start the car and check the lights, windows, and electronics - radio presets** and the clock reset. Reinstall the subwoofer (plug the connector in before the T30 screws), the spare tire, the retaining lug, and the floor covers.

TORQUE

Battery hold-down 11 Nm 8 ft-lbs

ezcarfix.com