2009-2013 Toyota Corolla - Alternator Replacement

2009-2013 Toyota Corolla | Moderate | 1-2 hours | $214 DIY

TOOLS

Ratchet and socket set (10mm, 12mm, 14mm) Breaker bar or long ratchet (for the belt tensioner) 10mm and 14mm combination wrenches Flat-blade screwdriver Digital multimeter Safety gloves Safety glasses

PARTS

Remanufactured Alternator (1.8L 2ZR-FE, 12V 100A, OE-style) 104210-5491 $190.00
Serpentine Drive Belt (inspect; replace if cracked or glazed) $24.00

STEPS

1. **Disconnect the battery - Turn the ignition off and remove the key. Using a 10mm socket,** loosen the negative (-) battery cable clamp and pull it off the terminal. Tuck it aside so it cannot touch the battery post while you work.
2. **Note the belt routing - Locate the alternator at the front of the 1.8L 2ZR-FE engine.** Take a clear photo of how the serpentine belt routes around every pulley, or sketch the routing on paper. You will need this to reinstall the belt correctly.
3. **Release the serpentine belt - Place a 14mm socket on the belt tensioner and rotate it** toward the passenger side (counter-clockwise) to unload the spring. Slip the belt off the alternator pulley while holding the tensioner. Release the tensioner slowly.
4. **Disconnect the alternator wiring - Press the release tab and pry the alternator connector** free with a flat-blade screwdriver - don't crack the plastic. Pull back the grey cover on the charging terminal, remove the 10mm nut, and lift the cable off.
5. **Unbolt the alternator - Remove the two 14mm bolts that mount the alternator to the engine** block. A breaker bar may help break them loose. Lay a folded rag over the exposed crank sensor wiring just below the alternator to protect it.
6. **Lift out the old alternator - Slide the alternator toward you off its lower mount, ease** it forward past the cooling hose, and lift it up and out of the engine bay without resting it on the crank sensor wires.
7. **Compare the replacement unit - Hold the new alternator next to the old one: mounting** ears, pulley groove count, rear-housing clocking, and electrical connector must all match. For the 2009-2013 Corolla 1.8L the OE-spec unit is a 12V 100A alternator.
8. **Install the new alternator - Lower the new alternator into place, seat it on the mounts,** and install the two mounting bolts. No factory torque spec was found in the sources reviewed - tighten securely and consult a 2009-2013 Corolla manual for the exact figure.
9. **Reconnect wiring and refit the belt - Reinstall the charging cable; tighten the 10mm nut,** plug the connector in until it clicks. Rotate the tensioner with the 14mm socket; slip the belt onto the alternator pulley. Confirm it sits fully in every groove before releasing.
10. **Reconnect the battery and test charging - Reconnect the battery cable and tighten the** 10mm clamp. Start the engine and measure voltage at the battery terminals: a healthy charging system reads 13.8V to 14.7V. Confirm the battery warning light is off and listen for unusual noises.

ezcarfix.com