

2006-2010 Volkswagen Jetta | Moderate | 2-3 hours | \$270 DIY

TOOLS

Flat Blade Screwdriver T20 Torx Driver
T25 Torx Driver T30 Torx Driver Ratchet
Wrench Needle Nose Pliers Socket
Extensions Trim Tool Set Pick Tool

PARTS

Window Regulator W0133-1910195 \$100.00
Window Motor \$150.00
Door Panel Clips W0133-1910197 \$20.00

STEPS

- 1 Disconnect the battery and remove the door panel - On the 2005-2010 Volkswagen Jetta:** disconnect the negative battery cable (important if the door has a side airbag). Pry off trim caps, remove Torx/panel screws, and carefully unclip the door panel. Unplug the window switch and any speakers...
- 2 Support the glass and expose the regulator - On the 2005-2010 Volkswagen Jetta:** peel back the vapor barrier carefully so you can reseal it later. Tape or clamp the window glass in the raised position. Locate the regulator bolts and motor connector through the access holes.
- 3 Separate the glass from the regulator - On the 2005-2010 Volkswagen Jetta:** loosen the glass clamp bolts or clips that hold the glass to the regulator channel. Lift the glass free of the regulator and secure it so it cannot drop. Do not force the glass against the run channels.
- 4 Unbolt the motor/regulator and remove it - On the 2005-2010 Volkswagen Jetta:** unplug the motor connector, remove the regulator mounting bolts, and snake the assembly out through the door cavity. Compare the new regulator (and motor if separate) to the old one before installing.
- 5 Install the new regulator and reattach the glass - On the 2005-2010 Volkswagen Jetta:** install the new regulator, torque mounting bolts, reconnect the motor, and seat the glass in the clamps. Tighten clamp bolts to spec while the glass sits square in the runs. Temporarily reconnect power an...
- 6 Reassemble the door and test auto-up - On the 2005-2010 Volkswagen Jetta:** reseal the vapor barrier, reconnect switches, and reinstall the door panel. Reconnect the battery. Initialize auto-up/down if required by holding the switch at the top/bottom stop. Confirm smooth travel a...