

2012-2017 Audi A5 | Easy | 10-15 minutes

TOOLS

Flathead screwdriver Damp cloth Dust mask

PARTS

Engine air filter for B8.5 A5 1.8/2.0 TFSI

STEPS

- 1 Locate the airbox - Open the hood on the B8.5 A5. The engine air filter box is on the passenger side of the engine bay. It is a large black plastic housing with an intake duct.**
- 2 Open the airbox lid - Release the metal clips around the airbox lid. On the B8.5 there are typically 4-6 clips. Lift the lid carefully without forcing it.**
- 3 Remove the old filter - Lift out the old filter and note which way it faces. The filter has a rubber seal that must orient correctly. Compare old and new for size.**
- 4 Install the new filter - Wipe the inside of the airbox with a damp cloth. Place the new filter in the same orientation. Ensure the seal sits flat.**
- 5 Close up and verify - Close the lid and secure all clips. Verify the intake duct is connected. Start the engine and confirm smooth idle.**
- 6 Test drive - Take a short drive to confirm normal power. A clean filter restores throttle response on the turbo engine.**