2015-2022 Chevrolet Trax - Tire Pressure & Rotation

2015-2022 Chevrolet Trax | Moderate | 45-75 minutes | $10 DIY

TOOLS

Tire-pressure gauge and air compressor or pump Floor jack, rated jack stands, and wheel chocks Lug wrench and calibrated torque wrench

PARTS

Valve-stem caps or replacement TPMS service parts only if inspection requires them $10.00

STEPS

1. **Check and set cold tire pressure from the door-jamb sticker - Open the driver’s door and** read the Tire and Loading Information label for the recommended cold pressure for your trim and factory tire size - the label is the authority, not the maximum on the tire sidewall.
2. **Loosen the lug nuts and lift the vehicle safely - You will need a torque wrench, a** breaker bar or the factory lug wrench, a floor jack, and jack stands. Crack the nuts about half a turn in a star pattern while each wheel is on the ground - do not remove them yet. Lift at the factory jac...
3. **Rotate the tires in the forward-cross pattern - On all-wheel-drive models the same cross** pattern applies with non-directional tires. Rotate about every 7,500 miles. While each wheel is off, measure tread depth, look for uneven wear that would warrant an alignment check, and inspect for...
4. **Reinstall the wheels and torque the lug nuts - Seat each wheel on the hub, start every** nut by hand to avoid cross-threading, and snug them in a star pattern. Recheck the lug-nut torque after 50-100 miles of driving.
5. **Relearn the TPMS and verify the job - On many of these Trax model years the TPMS relearns** itself as you drive - after several minutes at speed with correct pressures, the warning light goes out on its own. Take a short drive to confirm the display reads correctly with no warni...

TORQUE

ezcarfix.com