

2018-2022 Honda Accord | Moderate | 1 hour | \$40 DIY

TOOLS

Spark plug socket Ratchet Gap tool
Torque wrench Extension

PARTS

Spark plugs (set, spec gap) \$35.00

STEPS

- 1 Let the engine cool - Spark plugs go into the cylinder head. Removing them from a hot engine can damage the threads. Wait until the engine is cool to the touch.**
- 2 Remove the ignition coil - Disconnect the electrical connector, remove the coil hold-down bolt, and pull the coil straight up. Keep coils labeled by cylinder.**
- 3 Remove the old plug - Use the spark plug socket and ratchet to remove the old plug. Inspect the tip for oil fouling, glazing, or unusual wear.**
- 4 Gap and install the new plug - Set the gap on the new plug to spec. Thread it in by hand first to avoid cross-threading, then torque to the manual spec.**
- 5 Reinstall the coil - Reinstall the ignition coil, tighten the bolt, and reconnect the electrical connector. Repeat for all cylinders.**