2016-2021 Hyundai Tucson - Replace Cabin Air Filter

2016-2021 Hyundai Tucson | Easy | 30 minutes | $20 DIY

TOOLS
Glove Box Support Rod

PARTS
Cabin Air Filter BE-160 $20.00

STEPS

1. **Open glovebox and remove support rod - The 2016-2021 Tucson (TL) cabin filter is behind** the glovebox. You'll need: a new cabin filter; no tools required. Open and empty the glovebox, remove the stoppers on both sides, then remove the support rod - detached through the hole...
2. **Locate the filter cover - With the glovebox hanging down and the support rod detached,** look behind it for the filter cover. It's released by pressing the clips on both sides - that's the filter door.
3. **Remove the filter cover - Press the clips on both sides of the cover to release it and** set it aside. The filter is now visible - lift the old filter out of the housing.
4. **Remove the old filter - Lift the old filter out and note the airflow arrow - per the** owner's manual, it points DOWN. A dirty filter is why the Tucson's AC is weak.
5. **Install the new filter - Slide the new filter in with the arrow pointing DOWN (per the** owner's manual) and seat it fully. Press the cover back until the side clips engage; it should sit flush.
6. **Reassemble and test - Swing the glovebox back up, reinstall the support rod through the** right-side hole, and refit the stoppers on both sides. Test the climate control. Replace every 15,000-20,000 miles.

ezcarfix.com