2020-2024 Toyota Corolla - Engine Oil & Filter

2020-2024 Toyota Corolla | Moderate | 30-60 minutes | $57 DIY

TOOLS

Floor jack or ramps and rated jack stands if needed Oil-drain pan, funnel, gloves, and eye protection Socket or wrench for the drain plug and oil-filter tool
Calibrated torque wrench and shop towels
Oil Filter Cap Wrench

PARTS

Engine Oil (0W-20) $45.00
Correct engine oil filter and drain-plug washer for 2020-2024 Toyota Corolla Hybrid $12.00

STEPS

1. **Confirm oil specification and make the vehicle safe - The 2ZR-FXE 1.8L takes 4.4 US** quarts of 0W-20; filter is Toyota 04152-YZZA6 cartridge. Open the housing's small drain plug first so it empties cleanly without spilling. Park level, brake set, wheels chocked. Don't reuse the old O-rings.
2. **Warm briefly and protect the work area - Warm the engine 2-3 minutes. Gather a drain pan,** funnel, cartridge cap wrench, gloves, and the new 04152-YZZA6 element. Raise the front on ramps or jack stands; keep the key away while under the car - it can cycle on.
3. **Drain the used oil and replace the filter - Remove the drain plug. Open the housing's** drain plug first, then the cap. Fit the new 04152-YZZA6 element with fresh O-rings, confirming the old O-ring isn't stuck in the bore. Torque the cap by feel - plastic strips if forced.
4. **Install the correct oil quantity - Reinstall the drain plug with a fresh seal. Pour in** 4.4 quarts of 0W-20 through a funnel, adding the last quart slowly. Replace the oil cap. Measure, don't estimate. Wipe the dipstick fully before the final read.
5. **Check level, leaks, and service reminder - Press power to READY and check the housing and** plug for leaks. Shut down, wait a few minutes, and confirm the dipstick reads full. Reset the maintenance reminder via the steering-wheel buttons; recycle the used oil and cartridge.

TORQUE

ezcarfix.com