2017-2024 Alfa Romeo Giulia - Wiper Blade

2017-2024 Alfa Romeo Giulia | Easy | 15-20 minutes | $66 DIY

TOOLS

Tape measure Microfiber cloth and glass cleaner Small towel or rag

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99

STEPS

1. **Confirm 24/18 and the slim push-button arms - The Giulia takes 24 driver and 18** passenger blades - same fitment all years, including the Quadrifoglio. The arms use a slim 19mm push-button connector, so confirm the packaging lists the Giulia or the 19mm slim fitment.
2. **Activate the service position from the owner's manual - Use service position: stalk ring** to OFF, ignition to STOP. Within 2 minutes, push the stalk up into MIST and hold 3 seconds - they rise and stop. Miss the 2-minute window and the command is ignored.
3. **Lift the arm carefully - the washer jets are on it - Lift the arm away from the glass,** holding the metal arm. The washer jets are mounted on the wiper arms - don't yank outward or a hose can pop off its jet. Find the small release tab on the connector.
4. **Press the tab and slide the old blade off - Press the release tab and slide the blade** downward until it comes free. If the tab is stiff, press squarely and wiggle. Once off, lay the arm on a towel on the glass - a snapping arm can crack the windshield.
5. **Click the new blades on - 24 driver, 18 passenger - Align the arm tip with the new** 24 blade's channel and slide it up until the tab clicks. Tug to confirm the lock. Repeat with the 18 blade on the passenger side, then double-check neither washer hose was disturbed.
6. **Lower the arms and return them to rest - Lower both arms onto the windshield by hand,** then deactivate the service position: ignition to ON with the stalk in OFF and the blades on the glass. Never run the wipers while a blade is lifted off the glass. Don't drive off with the blade...
7. **Test the wipe, washers, and rain sensor area - Spray the washers and run the wipers** through all speeds. Check the spray lands ahead of each blade - a knocked hose sprays weakly or sideways. Keep the rain-sensor area by the interior mirror clean; dirt there confuses the auto wipers.

EZCarFix.com