2020-2021 BMW 2 Series Gran Coupe - Wiper Blade

2020-2021 BMW 2 Series Gran Coupe | Easy | 10-15 minutes | $66 DIY

TOOLS
Microfiber cloth

PARTS
Driver wiper blade, 22" Bosch 22A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99

STEPS

1. **Confirm the sizes and buy the blades - Buy one of each. The F44 uses a special** bayonet-style connector, so you need blades made specifically for this car - generic multi-adapter blades must have the bayonet adapter fitted. The Gran Coupe has no rear wiper.
2. **Put the wipers in service position - Start the car, switch it off, then press the wiper** stalk down and hold it until the blades sweep up and stop vertical. Never try to lift the arms from their parked position - you will gouge the hood paint.
3. **Release the old driver-side blade from the bayonet - Fold the driver-side arm up until it** holds. The F44 bayonet connector releases with a small locking catch on the blade's center adapter: slide or lift the catch, then slide the blade off the arm's bayonet pin. Pull the 26-inch blade free g...
4. **Prep the new driver-side blade - Verify the bayonet adapter is already fitted in the** blade's center - F44-specific blades come with it pre-installed, which is the whole point of buying the right set.
5. **Install the new blade and lock the catch - Tug the blade firmly to confirm it is captured** - an unlocked blade will slide straight back off. Lower the arm back onto the windshield gently, guiding it down by hand.
6. **Repeat on the passenger side - Do the same catch-release and install for the 17-inch** passenger blade. Check that the 26-inch blade is on the driver side - the 9-inch difference is big, so a mix-up is easy to spot but annoying to fix.
7. **Exit service position and test with washer fluid - Start the car and tap the wiper stalk** down once so the blades return to their normal park. Spray washer fluid and watch a full sweep for streaks, skipping, or chattering.

TORQUE

ezcarfix.com