2016-2020 Cadillac CT6 - Wiper Blade Replacement

2016-2020 Cadillac CT6 | Easy | 10-15 minutes for both front blades | $66 DIY

TOOLS

Tape measure or ruler Microfiber cloth and glass cleaner Folded towel (to cushion the windshield under a bare arm)

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99

STEPS

1. **Confirm the correct blade sizes for your CT6 - The CT6 (2016-2020) takes a 24-inch** driver-side and 18-inch passenger-side blade on standard J-hook arms; no rear wiper. Buy beam blades for J-hook arms. Measure the old blades tip to tip first - a previous owner may have fitted wrong...
2. **Park the car and lift the wiper arms - Park on level ground, parking brake set, ignition** off. The CT6 has no service position - pull each wiper away from the glass by hand. If blades are frozen, defrost fully first; tearing a frozen blade loose damages the rubber and overstre...
3. **Remove the old driver-side blade per the owner's manual - Lift the latch in the middle of** the blade. Slide the blade down toward the arm pivot until the J-hook releases, then slip it out sideways. Keep a firm grip on the arm - a bare arm snapping onto the glass can crack the windshield.
4. **Install the new 24-inch driver-side blade - Confirm the J-hook adapter is snapped into** the 24-inch blade's center clip. Feed the hook tip through the connector and pull the blade up until it clicks. Tug it along the arm to confirm it's locked - a loose blade can detach at highway...
5. **Replace the 18-inch passenger-side blade - Repeat on the passenger side with the 18-inch** blade: pull the arm away, lift the latch, slide the old blade off the J-hook. Install the new blade until the latch clicks, tug-test it, and lower it onto glass. Verify the blades don't collide...
6. **Clean the windshield and inspect the arms - Wipe the swept area with a microfiber cloth** so the dust film doesn't make new blades chatter. Check each arm's spring hinge - it should snap the arm down decisively; a weak spring lets the blade float and streak.
7. **Test the wipers and washers, then clean up - Ignition on, run the washer spray so the** glass is wet - never dry-run new blades; it destroys the rubber edge in seconds. Cycle through all speeds, checking for skipping or unwiped bands. If equipped, test rain-sensing mode and wipe the...

TORQUE

ezcarfix.com