# 2021-2024 Cadillac Escalade - Cabin Air Filter



**2021-2024 Cadillac Escalade | Easy | 15-25 minutes | $20 DIY**

**TOOLS**

Plastic trim tool  Small screwdriver (if required by the filter cover)  Gloves  Shop vacuum or clean rag

**PARTS**

Cabin air filter $20.00

## STEPS

1. **Prepare the vehicle and locate the filter - Park level, set the brake, ignition off. The** T1 Escalade’s cabin filter sits behind the glovebox - a single panel filter, so the swap is quick once the glovebox is lowered. Open the passenger door for room and confirm the replacement mat...
2. **Open the glovebox access - Empty the glovebox completely - it’s heavy when loaded and** will slam down on the trim when the stops release. Squeeze the side walls inward to clear the stop tabs, unhook the damper strap if equipped, and support the door as it swings do...
3. **Remove the old cabin filter - Release the clips on the rectangular filter cover and pull** it off. Slide the old filter out, noting the airflow arrow direction. Inspect the element for dust, leaves, moisture, or mold - a saturated filter is the usual cause of weak airf...
4. **Clean and install the new filter - Vacuum the empty tray so dust doesn’t fall into the** blower. Slide the new filter in with its airflow arrow matching the old filter’s direction - fully home, edges sealed, no gaps or folded corners. Refit the cover until its clips engage...
5. **Reassemble and test HVAC operation - Raise the glovebox past its stop tabs, reconnect the** damper strap if equipped, and close it - the latch should work smoothly. Run the HVAC through several fan speeds on fresh air: strong, clean airflow from all vents, no rattles or whist...

ezcarfix.com