2021-2024 Cadillac Escalade - Wiper Blade

2021-2024 Cadillac Escalade | Easy | 10-15 minutes | $81 DIY

TOOLS

tape measure (confirm 22"/22" front; rear 12" vs 11") clean rag folded towel (to protect the glass) step stool (optional - tall vehicle)

PARTS

Driver wiper blade, 22" Bosch 22A $32.99
Passenger wiper blade, 22" Bosch 22B $32.99
Rear wiper blade, 12" $14.99

STEPS

1. **Confirm the sizes and buy the right connectors - The Escalade takes 22 inches both sides.** The arms use a WIDE 22mm push-button (top-lock), not a J-hook - buy blades with that fitment. Rear: 12-inch blade on a 9x3 hook (one chart lists 11 - measure first).
2. **Park the wipers and get the arms up - Wipers off, ignition off. The front arms park on** the glass - no service mode. Lift the driver's arm until it stands. Work from the side on this tall truck - a step stool helps if you're short.
3. **Remove the old driver's-side blade - Press the button on the push-button housing and** slide the blade off the arm. Press the real release button, not the 22mm housing itself. Towel on the windshield under the arm; the acoustic-laminated glass is pricey to replace.
4. **Prep the new blade - Unwrap the new 22-inch blade and remove the edge protector. If** multi-adapter, swap to the wide 22mm push-button adapter per the instructions, clicking it into the blade's center. Compare against the old blade: 22 inches, wide push-button a...
5. **Install the new blade and verify the lock - Slide the blade up until the top button** clicks into the arm's hole. Tug hard and twist: the wide push-button must be fully engaged or it walks off at speed. Lower the arm and confirm the rubber lies flat.
6. **Passenger side and the 12-inch rear blade - Repeat the push-button routine on the** passenger side. For the rear: lift the arm - it only comes up partway - press the release tab and slide the old blade off. Click the new blade in and tug-test it.
7. **Test with washer fluid - Ignition on, run the front washers - both blades sweep clean,** quiet arcs. Run the rear washer and check the glass clears evenly. If a front blade chatters, the push-button isn't fully locked - reseat it. Top off the reservoir.

ezcarfix.com