2018-2024 Chevrolet Equinox - Wiper Blade

2018-2024 Chevrolet Equinox | Easy | 10-15 minutes | $81 DIY

TOOLS
tape measure clean towel washer fluid

PARTS
Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99
Rear wiper blade, 13" $14.99

STEPS

1. **Confirm your sizes and buy the blades - The third-gen Equinox takes a 24-inch driver and** 18-inch passenger blade up front. Charts disagree on the rear (most say 12, some 13) - measure yours before buying.
2. **Park the wipers where you can reach them - This generation parks on reachable glass with** no electronic service position - lift the arms by hand, no stalk tricks. Lay a towel on the windshield first; the springs are strong, and bare metal on glass is how windshields crack.
3. **Remove the old driver-side blade - Raise the driver's arm and slide a towel under it.** Press the release tab on the J-hook saddle and slide the old 24-inch blade down off the hook.
4. **Prep the new driver blade - Open the new 24-inch blade, check the J-hook adapter is** seated in the saddle, and peel the protector off the rubber edge. Compare the length and saddle against the old blade - 24 inches and an identical mount. This is the moment to catch...
5. **Install the new blade and verify the lock - Feed the new blade up into the hook until the** tab clicks over the arm tip. Tug firmly along the arm - it must not slide at all. Guide the arm down to the glass by hand; don't let the spring slam it.
6. **Passenger blade and the rear blade - Fit the 18-inch blade on the passenger side the same** way. Lower the arm onto the rear glass and give the blade a gentle tug to confirm it won't walk off the clip.
7. **Test with washer fluid - Refill the washer fluid and run the fronts and rear with the** washers. Watch for full, quiet sweeps and confirm the rear blade clears the back window evenly. If a blade chatters, its latch isn't fully home - re-seat it.

ezcarfix.com