2019-2024 Chevrolet Silverado 1500 - Cabin Air

2019-2024 Chevrolet Silverado 1500 | Easy | 15-25 minutes | $20 DIY

TOOLS
Flashlight Gloves Vacuum or rag for debris

PARTS
Cabin air filter $20.00

STEPS

1. **Prep and empty the glovebox - Park the Silverado on level ground, parking brake set,** ignition off. The cabin filter sits behind the glovebox - a tool-free job - so empty the glovebox completely. Chevrolet’s typical interval is a new filter every 12 months or 12,000...
2. **Expose the filter door - Unhook the dampener from the open glovebox first - fighting it** cracks the side stops. Squeeze both sides inward past the stops and let the box swing down. Behind it, squeeze the filter door’s side tabs and pull it straight off.
3. **Remove the old filter and clean - Slide the old filter out, noting the airflow arrow** direction first - on this truck the arrows point DOWNWARD. Wipe or vacuum the empty slot so debris doesn’t enter the HVAC case. The housing only flows one way, so match the old filter ex...
4. **Install the new filter - Insert the new filter with the airflow arrows pointing DOWN,** matching the old filter. Seat it fully flat with no gaps - gaps cause whistling on these trucks. Push it fully back before clipping the door shut; a short-seated filter whistle...
5. **Reassemble and verify airflow - Raise the glovebox past its side stops, reattach the** dampener, and close the box - confirm it latches. Set the fan to fresh air (not max recirculate) and run it through several speeds. Confirm strong, clean airflow with no whistling or r...

ezcarfix.com