# 2006-2013 Chevrolet Silverado 2500 - Wiper Blade



**2006-2013 Chevrolet Silverado 2500 | Easy | 10-15 minutes | $66 DIY**

**TOOLS**

Tape measure  Washer fluid for top-up  Stable step stool  Microfiber cloth and glass cleaner  Small towel or rag

**PARTS**

Driver wiper blade, 22" Bosch 22A $32.99
Passenger wiper blade, 22" Bosch 22B $32.99

## STEPS

1. **Confirm 22/22 across the generation split - The Silverado 2500 takes 22 on both** sides, with identical fitment on GMT800 (2006) and GMT900 (2007+). Some aftermarket charts mislist the 2006 passenger blade as 20, but GM's catalog specifies 22 for both - trust the tape measu...
2. **Park it and get stable access to the windshield - The arms park on the cowl - no service** position on this truck. Use a step stool; don't climb on the bumper or lean on the grille. Lift the driver's arm away from the glass; the arms have strong springs.
3. **Press the hook tab and slide the old blade off - Press the locking tab on the J-hook** squarely - angled pressure can snap aged plastic - and slide the 22 blade downward off the hook. If gummy, wiggle while pressing; don't pull straight and bend the hook. Towel under the arm.
4. **Seat the new 22 blade until it clicks - Thread the J-hook through the new 22 blade's** connector until the tab clicks. Tug hard to verify the latch. Switching to beam blades for winter? Confirm the included clip is the 93 hook type before leaving the store.
5. **Repeat on the passenger side - Repeat on the passenger side with the second 22 blade.** Both blades are identical, so there's no left/right to mix up - but replace them as a pair so both sides wipe evenly. Lower both arms by hand, gently.
6. **Top up washer fluid and check the nozzles - Top up the washer fluid. Run the washers and** check both nozzles spray a fan pattern. Clear leaves and debris from the cowl grille so the washer drains stay open - clogged cowls are common on trucks that sit outside.
7. **Test the wipe at all speeds - Run the wipers at low, high, and intermittent, dry and then** with washer fluid. Both blades should sweep silently with full contact - no chatter or missed bands. Confirm both arms park back on the cowl when switched off.

Ezcarfix.com