2021-2024 Chevrolet Trailblazer | Easy | 15 minutes | $81 DIY

TOOLS

Tape measure Folded shop towel Glass cleaner Washer fluid

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 18" Bosch 18B $32.99
Rear wiper blade, 12" $14.99

STEPS

1. **Move the wipers to service position - Shut the engine OFF, then within about 5 seconds** pull the wiper lever down to MIST and hold it - the GM service procedure parks the arms mid-windshield. Confirm the exact timing in your owner's manual if they don't move.
2. **Confirm the 24-inch and 18-inch front sizes - Don't confuse it with the original** 2002-2009 Trailblazer, the body-on-frame midsize SUV, which used 22-inch blades on both sides. Measure your old blades if a catalog shows anything else.
3. **Identify the push-button arm mount - Look at the joint and you'll see the round button** and its release tab. Aftermarket blades sold for this car include a multi-adapter that covers this mount, but check the box lists the button-type adapter before you leave the store.
4. **Release the old front blades - Lift each arm off the glass and pad the tip with a towel.** Squeeze the release tab on the blade connector and slide the blade off the button mount, working it toward the wiper tip.
5. **Snap the new front blades on - Press each new blade's connector onto the button until it** clicks - then pull back on the blade to verify the latch. Lower each arm onto the glass by hand instead of letting it snap down.
6. **Handle the rear wiper - Lift the rear arm gently - rear arms are lightly sprung - release** the old blade from its small hook, click the new one on, and test it with the rear washer.
7. **Test everything and set the interval - Start the vehicle, run the front washers, and** cycle low, high, and intermittent speeds. Test the rear wiper separately with its own washer jet on the tailgate. The arms return to their hidden park automatically.

TORQUE

ezcarfix.com