2009-2017 Chevrolet Traverse - Wiper Blade

2009-2017 Chevrolet Traverse | Easy | 10-20 minutes | $81 DIY

TOOLS

Soft towel to protect the glass Small flat screwdriver only if the adapter requires it Gloves and a clean cloth

PARTS

Driver wiper blade, 24" Bosch 24A $32.99
Passenger wiper blade, 21" Bosch 21B $32.99
Rear wiper blade, 13" $14.99

STEPS

1. **Get the right blades: 24" driver, 21" passenger, 13" rear (pinch-tab) - The 2009-2017** Chevrolet Traverse takes a 24-inch driver-side blade, a 21-inch passenger-side blade, and a 13-inch rear blade. Replace all three at once - on a vehicle this size, the rear wiper does real work and a worn one leaves the bac...
2. **Protect the glass - Lift one Traverse wiper arm at a time and rest a folded towel on the** windshield beneath it. A bare arm snapping back under spring tension can crack the glass.
3. **Remove the old blade - Squeeze the pinch tabs on the Traverse’s blade connector and slide** the blade off the arm. Pull in line with the arm and avoid bending it sideways, which weakens wiper pressure.
4. **Install - Install the 24-inch blade on the driver side and the 21-inch blade on the** passenger side, and fit the 13-inch blade on the rear arm. Confirm each blade lies flat with the rubber edge facing the glass.
5. **Test with washer fluid - Lower every arm gently onto the glass, top off the washer fluid,** and test the front and rear washers. Each sweep should be streak-free and quiet across the full arc.

ezcarfix.com