2017-2025 Chrysler Pacifica - Oil Change

2017-2025 Chrysler Pacifica | Moderate | 30-45 minutes | $47 DIY

TOOLS

Jack and jack stands (or ramps) Oil drain pan Socket set / wrench Oil filter wrench Torque wrench Funnel Rubber gloves Safety glasses Rags 24mm Socket 13mm Socket

PARTS

Engine Oil (0W-20 full synthetic) $35.00
Oil filter cartridge element kit (with O-rings) $12.00
Drain Plug Crush Washer $3.00

STEPS

1. **Prepare the vehicle - Have a 24mm or 15/16-inch socket for the filter cap, a 13mm socket** for the drain plug, and a funnel ready. Park on level ground with the engine warm. It uses a cartridge filter - Mopar MO-349 for 2014 and newer; do not use the older MO-7...
2. **Lift and support safely - Parking brake set, wheels chocked. Lift the front at the** designated jacking points and support it on jack stands - never on the jack alone. The filter cap is on top of the engine; the drain plug is underneath.
3. **Drain the oil - Remove the oil fill cap to vent the crankcase. Slide the drain pan under** the oil pan, remove the 13mm drain plug, and drain fully. The plug tightens to about 20 ft-lbs on reinstall. Wipe the pan flange clean.
4. **Replace the oil filter - Unscrew the filter cap on top of the engine with the 24mm socket** and lift out the old cartridge - it clicks into the cap, so pull it free. Replace the cap's O-ring with the new one from the filter kit, lubricating it with fresh oil, and...
5. **Refit drain plug and refill - Reinstall the drain plug to about 20 ft-lbs. Lower the** vehicle to level ground and pour in 5.0 quarts of 0W-20 through a funnel. Wait a minute, then check the dipstick - confirm the level is at the full mark.
6. **Check for leaks and reset - Start the engine for about 30 seconds, shut it off, and** inspect the filter cap and drain plug for leaks. Recheck the dipstick after a short drive. Reset the oil-life monitor through the cluster menu, then recycle the used oil and element.

TORQUE

Oil Drain Plug 27 Nm 20 ft-lbs
Oil Filter (hand-tight only)

ezcarfix.com