2015-2024 Ford Transit - Brake Pad Replacement

2015-2024 Ford Transit | Advanced | 1-3 hours | $205 DIY

TOOLS

Floor jack, rated jack stands, and wheel chocks Lug wrench and calibrated torque wrench Brake piston compressor or suitable spreader Socket set, wire brush, brake cleaner, gloves, and eye protection
15mm Socket

PARTS

Front or rear brake pad set for 2015-2024 Ford Transit; verify axle, brake package, and VIN fitment $180.00
Replacement pad hardware or wear sensor only if the kit requires it $25.00

STEPS

1. **Confirm axle, parts, and brake condition - Confirm a US full-size Transit - not a Connect** or Custom. Front calipers are floating dual-piston with 48mm steel pistons. Replace the bracket bolts and bolt-and-pin kit if corroded; check rotor thickness and heat cracking.
2. **Lift and secure the vehicle - Set the parking brake; use a jack and stands rated for this** van. Break the lug nuts loose, jack the front at the frame rails, and remove the wheel. Siphon the reservoir down from MAX.
3. **Remove the caliper and old pads - Remove the caliper slide bolts (15mm socket), lift the** caliper off the bracket, and hang it - never by the hose. Slide out the old pads; inspect the pins and boots.
4. **Install pads and hardware - Retract both pistons together with a dual-piston compressor,** watching the reservoir. Lube the cleaned pins with silicone brake lubricant. Fit new abutment clips, seat the new pads, and lower the caliper over them.
5. **Torque and bed in - Torque the bracket bolts to 129 Nm (95 ft-lb). Torque the slide** bolts to Ford’s lower spec; don’t mix them up. Torque the lug nuts to 150 Nm (111 ft-lb), then bed the pads.

TORQUE

ezcarfix.com