2016-2024 Honda BR-V - Engine Oil & Filter Change

2016-2024 Honda BR-V | Moderate | 30-60 minutes | $57 DIY

TOOLS

Floor jack or ramps and rated jack stands if needed Oil-drain pan, funnel, gloves, and eye protection Socket or wrench for the drain plug and oil-filter tool
Calibrated torque wrench and shop towels
14mm Socket

PARTS

Engine Oil (0W-20) $45.00
Correct engine oil filter and drain-plug washer for 2016-2024 Honda BR-V $12.00

STEPS

1. **Confirm oil specification and make the vehicle safe - The BR-V’s 1.5L L15Z1 petrol engine** takes 3.6 liters of oil with a filter change. Honda lists 0W-20, 0W-30, 5W-30, or 10W-30 meeting API SM or higher - 0W-20 is the best all-round choice. The diesel 1.5L N15A1 BR-V takes 4.4 liters of 0W-3...
2. **Warm briefly and protect the work area - Loosen the lug nuts while the wheels are on the** ground, then raise the front with a floor jack and set it on rated jack stands under the frame rails. Idle 2-3 minutes so the oil drains fully, then switch off and wait a minute for the exhau...
3. **Drain the used oil and replace the filter - Find the drain plug on the oil pan - a 14mm** socket fits Honda’s L-series plug. Confirm the old gasket came away, oil the new gasket, and tighten hand-tight plus three-quarters of a turn.
4. **Install the correct oil quantity - Pour 3.6 liters of 0W-20 through a funnel; diesels get** 4.4 liters. Refit the filler cap, then check the dipstick: wipe, reinsert fully, and confirm the level sits between the marks with the car level.
5. **Check level, leaks, and service reminder - Start the engine and idle about a minute so** the new filter fills; the oil light should go out quickly. Switch off, wait 2-3 minutes, recheck the dipstick, and top up if needed. Look underneath at the drain plug and filter for weeping.

TORQUE

ezcarfix.com