2010-2015 Honda Crosstour - Wiper Blade Replacement

2010-2015 Honda Crosstour | Easy | 10-15 minutes | $66 DIY

TOOLS

Flathead screwdriver wrapped in a cloth - to lift the lock tabs on Honda OE blades Tape measure - to confirm 26"/19"/21" before buying Clean cloth - to protect the glass under raised arms Fine pin - to clear a clogged rear washer nozzle (optional)

PARTS

Driver wiper blade, 26" Bosch 26A $32.99
Passenger wiper blade, 19" Bosch 19B $32.99
Rear wiper blade, 21"

STEPS

1. **Confirm the fitment: 26-inch driver, 19-inch passenger, 21-inch rear - The 2010-2015** Crosstour - "Accord Crosstour" for 2010-2011 - takes 26 driver, 19 passenger, 21 rear, on J-hooks. Catalogs disagree: Honda's own refill is 525 mm - buy 21. Fronts use Honda's lock-tab connection - read step 3 fir...
2. **Park, power off - no service position needed - Park level, ignition off, wiper stalk OFF.** No service position - lift the arms. Honda's order: driver-side arm up first, passenger-side down first when done - the arms overlap at rest, and this order prevents clashing. Towel under the...
3. **Release the lock tab and remove the driver-side blade - Lift the arm. On Honda OE blades,** pry the lock tab up with a wrapped flathead, then slide the blade off arm's end. If owner fitted J-hook blades, press the press-tab and slide the blade off hook. Keep it straight.
4. **Install the new 26-inch driver-side blade - Slide the 26-inch blade on from the arm's** end, then push the lock tab flat - the tab is the retention - left up, the blade can walk off. Aftermarket J-hook blade: slide up until its tab clicks. Tug, lower.
5. **Repeat on the 19-inch passenger blade - Repeat with the 19-inch blade on the passenger** side. Don't mix sides - 26 inches is the driver's. Check hinges; the arms sit in the debris zone, and a stiff hinge causes uneven pressure and streaking new blades won't fix.
6. **Swap the 21-inch rear blade - Raise the rear arm. The rear blade is also lock-tab: pry** the lock tab up with a screwdriver; slide the blade out. Slide the 21-inch blade on, engaging holder's tab in the indent; push the lock tab flat and lower.
7. **Test all three wipers - Ignition on: test the fronts at speeds, watching for streaks or** chatter. Lower the passenger arm first, then recheck rest overlapping parked. Run the rear wiper and washer - hatch nozzle clogs; clear it with a pin if weak.

ezcarfix.com