2019-2024 Lexus UX - Cabin Air Filter Replacement

2019-2024 Lexus UX | Easy | About 10 minutes | $28 DIY

TOOLS

No tools required - stops and cover release by hand Small flat plastic trim tool (optional) if a cover clip proves stubborn Flashlight or phone light for inspecting the filter compartment Dry cloth for wiping debris out of the compartment

PARTS

Cabin air filter for 2019-2024 Lexus UX; verify arrows, size, and VIN/trim fitment $28.00

STEPS

1. **Find the cabin filter behind the glove box - Turn the car fully off. This covers the UX** 200 and UX 250h, but note the 250h has a second, separate filter: the hybrid battery intake filter behind the rear seat. This guide covers only the cabin filter.
2. **Empty the glove box - Open the glove box and take everything out - you'll press the sides** past their stops so the box swings down farther than normal, and anything inside will slide into the footwell or wedge against the dash.
3. **Release the side stops and swing the box down - Press inward on both sides of the open** glove box so the stops clear the dash frame, then let it swing down and hang on its hinges. The stops are designed to be overridden - press evenly on both sides.
4. **Pull the plastic cover toward you - Below the lowered glove box you will find the** compartment containing the filter, protected by a plastic cover. Remove the cover by pulling it toward you - it unclips by hand with no screws. Note the cover's orientation as it comes off so...
5. **Slide out the old filter and note its orientation - Slide the old filter out and note its** orientation. On OEM Lexus filters the arrow points up; on many aftermarket filters it marks airflow direction and points down - air flows downward here. Match your filter's instructions and compare o...
6. **Install the new filter and close everything up - Slide the new filter in correctly** oriented until it seats fully and evenly. Refit the plastic cover until all clips engage. Swing the glove box up, press the sides so the stops re-engage, and confirm it opens, closes, and latches normally.
7. **Test the HVAC and remember the hybrid's second filter - Run the fan on high through the** vents, floor, and defrost. Airflow should feel strong with no whistling or buzzing - noise means the filter or cover isn't seated. The UX 250h's hybrid battery intake filter is a separate item behind the r...

TORQUE

ezcarfix.com