2015-2021 Nissan Frontier - Cabin Air Filter

2015-2021 Nissan Frontier | Easy | 15-25 minutes | $20 DIY

TOOLS
Trim tool or flat screwdriver (optional)
Flashlight Gloves Vacuum or rag for debris

PARTS
Cabin air filters (pair) $20.00

STEPS

1. **Prep and empty the glovebox - Park the Frontier, set the parking brake, and empty the** glovebox. The D40 takes two small cabin filters stacked behind the glovebox on the passenger side - buy the pair and confirm both match before starting.
2. **Expose the filter door - Push both glovebox sides inward until the stop pins clear,** letting it swing fully down - unhook the right-side dampener cord first. Unfasten the clasp on the filter access door and remove it.
3. **Remove the old filter and clean - Slide both old filters out one at a time, noting the** airflow arrows (down on the Frontier). Bag them, then vacuum leaves and dust from the slot so debris doesn't fall into the HVAC case.
4. **Install the new filter - Slide the two new filters in one at a time, arrows down - push** the first fully to one side, then the second beside it. Seat both fully flat; bent frames or edge gaps let unfiltered air bypass.
5. **Reassemble and verify airflow - Refit the access door until the clasp clicks. Lift the** glovebox until the stop pins re-engage and reattach the dampener cord. Start up on fresh air (not recirculate) and confirm strong, rattle-free airflow - a whistle means a crooked fil...

ezcarfix.com